SHOWER/UTILITY SHELF 320MM

SPECIFICATIONS



Secure 4 point fixing system






Available Finishes



INSTALLATION NOTES:

Remove cover plate by twisting and pulling back. Screws & plugs supplied are for timber or masonry fixing. Use toggle bolts for plaster or cavity walls, (Not provided). There are four fixing points but two should be adequate, we recommend always using top and bottom fixing points.



270

